



VGJ9240

POWERED STUDIO MONITOR

HS4

HS3




https://manual.yamaha.com/pa/speakers/hs4_hs3/

- EN** Quick Start Guide
- DE** Schnellstartanleitung
- FR** Guide de démarrage rapide
- ES** Guía de inicio rápido
- PT** Guia de início rápido
- IT** Guida rapida
- RU** краткое руководство
- ZH-CN** 快速入门指南
- ZH-TW** 快速入門指南
- KO** 빠른 시작 가이드
- JA** クイックスタートガイド

POWERED SPEAKER SYSTEM
SYSTÈME D'ENCEINTES AMPLIFIÉES
SISTEMA DE ALTAVOZ ACTIVO
SISTEMA DE CAIXAS ATIVAS
АКТИВНАЯ АКУСТИЧЕСКАЯ СИСТЕМА
有源音箱
主動式喇叭
앰프내장형 스피커
パワードスピーカーシステム




1




A




B




2



3



4



5

