
DIGITAL KEYBOARD

Drum Kit List

PSR-1300

Drum Kit List

- Each percussion voice uses one-note polyphony.
- The MIDI Note # and Note are actually one octave lower than keyboard Note # and Note. For example, in "Standard Kit 1," the "Seq Click H" (Note #36/ Note C1) corresponds to MIDI (Note #24/Note C0).
- Same as "Standard Kit 1"
- No Sound

Voice No.				260	261	262	263	264	265	266	
MSB (0-127) / LSB (0-127) / PC (1-128)				127/000/088	127/000/001	127/000/002	127/000/009	127/000/017	127/000/025	127/000/026	
Keyboard				MIDI	Power Kit	Standard Kit 1	Standard Kit 2	Room Kit	Rock Kit	Electronic Kit	Analog Kit
Note #	Note	Note #	Note								
25	C# 0	13	C# -1		Surdo Mute						
26	D 0	14	D -1		Surdo Open						
27	D# 0	15	D# -1		Hi Q						
28	E 0	16	E -1		Whip Slap						
29	F 0	17	F -1		Scratch H						
30	F# 0	18	F# -1		Scratch L						
31	G 0	19	G -1		Finger Snap						
32	G# 0	20	G# -1		Click Noise						
33	A 0	21	A -1		Metronome Click						
34	A# 0	22	A# -1		Metronome Bell						
35	B 0	23	B -1		Seq Click L						
36	C 1	24	C 0		Seq Click H						
37	C# 1	25	C# 0		Brush Tap						
38	D 1	26	D 0		Brush Swirl						
39	D# 1	27	D# 0		Brush Slap						
40	E 1	28	E 0		Brush Tap Swirl				Reverse Cymbal	Reverse Cymbal	
41	F 1	29	F 0		Snare Roll						
42	F# 1	30	F# 0		Castanet				Hi Q 2	Hi Q 2	
43	G 1	31	G 0	Snare Soft Power	Snare Soft	Snare Soft 2		Snare Noisy	Snare Snappy Electronic	Snare Noisy 4	
44	G# 1	32	G# 0		Sticks						
45	A 1	33	A 0	Kick Amb-	Bass Drum Soft				Bass Drum H	Bass Drum H	
46	A# 1	34	A# 0	Open Rim Power	Open Rim Shot	Open Rim Shot 2					
47	B 1	35	B 0	Kick Power Open	Bass Drum Hard			Bass Drum H	Bass Drum Rock	Bass Drum Analog L	
48	C 2	36	C 1	Kick Power Closed	Bass Drum	Bass Drum 2		Bass Drum Rock	Bass Drum Gate	Bass Drum Analog H	
49	C# 2	37	C# 1	Side Stick Power	Side Stick					Side Stick Analog	
50	D 2	38	D 1	Snare Power	Snare	Snare 2	Snare Room L	Snare Rock	Snare Noisy 2	Snare Analog 1	
51	D# 2	39	D# 1	Hand Clap Power	Hand Clap						
52	E 2	40	E 1	Snare Rough	Snare Tight	Snare Tight 2	Snare Room H	Snare Rock Rim	Snare Noisy 3	Snare Analog 2	
53	F 2	41	F 1	Tom Power 1	Floor Tom L		Tom Room 1	Tom Rock 1	Tom Electronic 1	Tom Analog 1	
54	F# 2	42	F# 1	Hi-Hat Closed Power	Hi-Hat Closed					Hi-Hat Closed Analog 1	
55	G 2	43	G 1	Tom Power 2	Floor Tom H		Tom Room 2	Tom Rock 2	Tom Electronic 2	Tom Analog 2	
56	G# 2	44	G# 1	Hi-Hat Pedal Power	Hi-Hat Pedal					Hi-Hat Closed Analog 2	
57	A 2	45	A 1	Tom Power 3	Low Tom		Tom Room 3	Tom Rock 3	Tom Electronic 3	Tom Analog 3	
58	A# 2	46	A# 1	Hi-Hat Open Power	Hi-Hat Open					Hi-Hat Open Analog	
59	B 2	47	B 1	Tom Power 4	Mid Tom L		Tom Room 4	Tom Rock 4	Tom Electronic 4	Tom Analog 4	
60	C 3	48	C 2	Tom Power 5	Mid Tom H		Tom Room 5	Tom Rock 5	Tom Electronic 5	Tom Analog 5	
61	C# 3	49	C# 2	Crash Cymbal Acoustic 1	Crash Cymbal 1					Crash Analog	
62	D 3	50	D 2	Tom Power 6	High Tom		Tom Room 6	Tom Rock 6	Tom Electronic 6	Tom Analog 6	
63	D# 3	51	D# 2	Ride Cymbal Acoustic 1	Ride Cymbal 1						
64	E 3	52	E 2	Chinese Cymbal Acoustic	Chinese Cymbal						
65	F 3	53	F 2	Ride Cymbal Cup Acoustic	Ride Cymbal Cup						
66	F# 3	54	F# 2		Tambourine						
67	G 3	55	G 2	Splash Cymbal Acoustic	Splash Cymbal						
68	G# 3	56	G# 2		Cowbell					Cowbell Analog	
69	A 3	57	A 2	Crash Cymbal Acoustic 2	Crash Cymbal 2						
70	A# 3	58	A# 2		Vibraslap						
71	B 3	59	B 2	Ride Cymbal Acoustic 2	Ride Cymbal 2						
72	C 4	60	C 3		Bongo H						
73	C# 4	61	C# 3		Bongo L						
74	D 4	62	D 3		Conga H Mute					Conga Analog H	
75	D# 4	63	D# 3		Conga H Open					Conga Analog M	
76	E 4	64	E 3		Conga L					Conga Analog L	
77	F 4	65	F 3		Timbale H						
78	F# 4	66	F# 3		Timbale L						
79	G 4	67	G 3		Agogo H						
80	G# 4	68	G# 3		Agogo L						
81	A 4	69	A 3		Cabasa						
82	A# 4	70	A# 3		Maracas					Maracas 2	
83	B 4	71	B 3		Samba Whistle H						
84	C 5	72	C 4		Samba Whistle L						
85	C# 5	73	C# 4		Guiro Short						
86	D 5	74	D 4		Guiro Long						
87	D# 5	75	D# 4		Claves					Claves 2	
88	E 5	76	E 4		Wood Block H						
89	F 5	77	F 4		Wood Block L						
90	F# 5	78	F# 4		Cuica Mute				Scratch H	Scratch H	
91	G 5	79	G 4		Cuica Open				Scratch L	Scratch L	
92	G# 5	80	G# 4		Triangle Mute						
93	A 5	81	A 4		Triangle Open						
94	A# 5	82	A# 4		Shaker						
95	B 5	83	B 4		Jingle Bells						
96	C 6	84	C 5	Wind Chime	Bell Tree						
97	C# 6	85	C# 5								
98	D 6	86	D 5								
99	D# 6	87	D# 5								
100	E 6	88	E 5								
101	F 6	89	F 5								
102	F# 6	90	F# 5								
103	G 6	91	G 5								

		Voice No.				261	267	268	269	270	271
		MSB (0-127) / LSB (0-127) / PC (1-128)				127/000/001	127/000/113	127/000/033	127/000/041	127/000/049	126/000/128
		MIDI				Standard Kit 1	Dance Kit	Jazz Kit	Brush Kit	Symphony Kit	Chinese Kit
	Note #	Note	Note #	Note							
	25	C# 0	13	C# -1	Surdo Mute						
	26	D 0	14	D -1	Surdo Open						
	27	D# 0	15	D# -1	Hi Q						
	28	E 0	16	E -1	Whip Slap						
	29	F 0	17	F -1	Scratch H						
	30	F# 0	18	F# -1	Scratch L						
	31	G 0	19	G -1	Finger Snap						
	32	G# 0	20	G# -1	Click Noise						
	33	A 0	21	A -1	Metronome Click						
	34	A# 0	22	A# -1	Metronome Bell						
	35	B 0	23	B -1	Seq Click L						
	36	C 1	24	C 0	Seq Click H						
	37	C# 1	25	C# 0	Brush Tap						
	38	D 1	26	D 0	Brush Swirl						
	39	D# 1	27	D# 0	Brush Slap						
	40	E 1	28	E 0	Brush Tap Swirl	Reverse Cymbal					
	41	F 1	29	F 0	Snare Roll						
	42	F# 1	30	F# 0	Castanet	Hi Q 2					
	43	G 1	31	G 0	Snare Soft	Snare Techno		Brush Slap 2			
	44	G# 1	32	G# 0	Sticks						
	45	A 1	33	A 0	Bass Drum Soft	Kick Techno Q			Bass Drum Soft L		
	46	A# 1	34	A# 0	Open Rim Shot	Rim Gate					
	47	B 1	35	B 0	Bass Drum Hard	Kick Techno L			Gran Cassa		
	48	C 2	36	C 1	Bass Drum	Kick Techno	Bass Drum Jazz	Bass Drum Jazz	Gran Cassa Mute		
	49	C# 2	37	C# 1	Side Stick	Side Stick Analog					
	50	D 2	38	D 1	Snare	Snare Clap	Snare Jazz L	Brush Slap 3	Band Snare 1		
	51	D# 2	39	D# 1	Hand Clap						
	52	E 2	40	E 1	Snare Tight	Snare Dry	Snare Jazz M	Brush Tap	Band Snare 2		
	53	F 2	41	F 1	Floor Tom L	Tom Analog 1	Tom Jazz 1	Tom Brush 1			
	54	F# 2	42	F# 1	Hi-Hat Closed	Hi-Hat Closed Analog 3					
	55	G 2	43	G 1	Floor Tom H	Tom Analog 2	Tom Jazz 2	Tom Brush 2	Tom Jazz 2		
	56	G# 2	44	G# 1	Hi-Hat Pedal	Hi-Hat Closed Analog 4					
	57	A 2	45	A 1	Low Tom	Tom Analog 3	Tom Jazz 3	Tom Brush 3	Tom Jazz 3		
	58	A# 2	46	A# 1	Hi-Hat Open	Hi-Hat Open Analog 2					
	59	B 2	47	B 1	Mid Tom L	Tom Analog 4	Tom Jazz 4	Tom Brush 4	Tom Jazz 4		
	60	C 3	48	C 2	Mid Tom H	Tom Analog 5	Tom Jazz 5	Tom Brush 5	Tom Jazz 5		
	61	C# 3	49	C# 2	Crash Cymbal 1	Crash Analog			Hand Cymbal 1		
	62	D 3	50	D 2	High Tom	Tom Analog 6	Tom Jazz 6	Tom Brush 6	Tom Jazz 6		
	63	D# 3	51	D# 2	Ride Cymbal 1				Hand Cymbal 1 Short		
	64	E 3	52	E 2	Chinese Cymbal						
	65	F 3	53	F 2	Ride Cymbal Cup						
	66	F# 3	54	F# 2	Tambourine						
	67	G 3	55	G 2	Splash Cymbal						
	68	G# 3	56	G# 2	Cowbell	Cowbell Analog					
	69	A 3	57	A 2	Crash Cymbal 2				Hand Cymbal 2		
	70	A# 3	58	A# 2	Vibraslap						
	71	B 3	59	B 2	Ride Cymbal 2				Hand Cymbal 2 Short		
	72	C 4	60	C 3	Bongo H						
	73	C# 4	61	C# 3	Bongo L						
	74	D 4	62	D 3	Conga H Mute	Conga Analog H					
	75	D# 4	63	D# 3	Conga H Open	Conga Analog M					
	76	E 4	64	E 3	Conga L	Conga Analog L					
	77	F 4	65	F 3	Timbale H						
	78	F# 4	66	F# 3	Timbale L						
	79	G 4	67	G 3	Agogo H					Dagu Mute	
	80	G# 4	68	G# 3	Agogo L					Zhongcha Mute	
	81	A 4	69	A 3	Cabasa					Dagu Heavy	
	82	A# 4	70	A# 3	Maracas	Maracas 2				Zhongcha Open	
	83	B 4	71	B 3	Samba Whistle H					Paigu Middle	
	84	C 5	72	C 4	Samba Whistle L					Paigu Low	
	85	C# 5	73	C# 4	Guiro Short					Xiaocha Mute	
	86	D 5	74	D 4	Guiro Long					Bangu	
	87	D# 5	75	D# 4	Claves	Claves 2				Xiaocha Open	
	88	E 5	76	E 4	Wood Block H					Bangzi	
	89	F 5	77	F 4	Wood Block L					Muyu Low	
	90	F# 5	78	F# 4	Cuica Mute	Scratch H				Zhongluo Mute	
	91	G 5	79	G 4	Cuica Open	Scratch L				Muyu Mid-Low	
	92	G# 5	80	G# 4	Triangle Mute					Zhongluo Open	
	93	A 5	81	A 4	Triangle Open					Muyu Middle	
	94	A# 5	82	A# 4	Shaker					Xiaoluo Open	
	95	B 5	83	B 4	Jingle Bells					Triangle Mute	
	96	C 6	84	C 5	Bell Tree					Triangle Open	
	97	C# 6	85	C# 5							
	98	D 6	86	D 5							
	99	D# 6	87	D# 5							
	100	E 6	88	E 5							
	101	F 6	89	F 5							
	102	F# 6	90	F# 5							
	103	G 6	91	G 5							

Drum Kit List

	No.	261		272		273		274		275				
		MSB (0-127) / LSB (0-127) / PC (1-128)		127/000/001		126/000/055		126/000/056		126/000/057		126/000/037		
		Keyboard		MIDI		Standard Kit 1		Indonesian Kit 1		Indonesian Kit 2		Indonesian Kit 3		Arabic Kit
Note #	Note	Note #	Note											
	25	C#	0	13	C#	-1	Surdo Mute			Low Dut Slide 1		Zarb Back mf		
	26	D	0	14	D	-1	Surdo Open			Low Dut Slide 2		Zarb Tom f		
	27	D#	0	15	D#	-1	Hi O			Low Dut Slide 3		Zarb Eshareh		
	28	E	0	16	E	-1	Whip Slap			Plak 2 Ring Open		Zarb Whipping		
	29	F	0	17	F	-1	Scratch H			Plak 2 Ring Mute		Tombak Tom f		
	30	F#	0	18	F#	-1	Scratch L			Plak 2 Mute Center		Neghareh Tom f		
	31	G	0	19	G	-1	Finger Snap			Plak 2 Open		Tombak Back f		
	32	G#	0	20	G#	-1	Click Noise					Neghareh Back f		
	33	A	0	21	A	-1	Metronome Click					Tombak Snap f		
	34	A#	0	22	A#	-1	Metronome Bell					Neghareh Pelang f		
	35	B	0	23	B	-1	Seq Click L					Tombak Trill		
	36	C	1	24	C	0	Seq Click H					Tombak Clap 1		
	37	C#	1	25	C#	0	Brush Tap					Arabic Zalqouta Open		
	38	D	1	26	D	0	Brush Swirl					Khaligi Clap 2		
	39	D#	1	27	D#	0	Brush Slap					Arabic Zalqouta Close		
	40	E	1	28	E	0	Brush Tap Swirl					Arabic Hand Clap		
	41	F	1	29	F	0	Snare Roll					Tabel Tak 1		
	42	F#	1	30	F#	0	Castanet					Sagat 1		
	43	G	1	31	G	0	Snare Sort					Tabel Dom		
	44	G#	1	32	G#	0	Sticks					Sagat 2		
	45	A	1	33	A	0	Bass Drum Soft					Tabel Tak 2		
	46	A#	1	34	A#	0	Open Rim Shot					Sagat 3		
	47	B	1	35	B	0	Bass Drum Hard					Riq Tik 3		
	48	C	2	36	C	1	Bass Drum					Riq Tik 2		
	49	C#	2	37	C#	1	Side Stick					Riq Tik Hard 1		
	50	D	2	38	D	1	Snare					Riq Tik 1		
	51	D#	2	39	D#	1	Hand Clap					Riq Tik Hard 2		
	52	E	2	40	E	1	Snare Tight					Riq Tik Hard 3		
	53	F	2	41	F	1	Floor Tom L					Riq Fish		
	54	F#	2	42	F#	1	Hi-Hat Closed					Riq Snouj 2		
	55	G	2	43	G	1	Floor Tom H					Riq Roll		
	56	G#	2	44	G#	1	Hi-Hat Pedal					Riq Snouj 1		
	57	A	2	45	A	1	Low Tom					Riq Sak		
	58	A#	2	46	A#	1	Hi-Hat Open					Riq Snouj 3		
	59	B	2	47	B	1	Mid Tom L					Riq Snouj 4		
	60	C	3	48	C	2	Mid Tom H					Riq Tak 1		
	61	C#	3	49	C#	2	Crash Cymbal 1					Riq Brass 1		
	62	D	3	50	D	2	High Tom					Riq Tak 2		
	63	D#	3	51	D#	2	Ride Cymbal 1					Riq Brass 2		
	64	E	3	52	E	2	Chinese Cymbal					Riq Dom		
	65	F	3	53	F	2	Ride Cymbal Cup					Katemb Tak Doff		
	66	F#	3	54	F#	2	Tambourine					Katemb Dom		
	67	G	3	55	G	2	Splash Cymbal					Katemb Sak 1		
	68	G#	3	56	G#	2	Cowbell					Katemb Tak 1		
	69	A	3	57	A	2	Crash Cymbal 2					Katemb Sak 2		
	70	A#	3	58	A#	2	Vibraslap					Katemb Tak 2		
	71	B	3	59	B	2	Ride Cymbal 2					Daholia Sak 2		
	72	C	4	60	C	3	Bongo H	Kendang Ageng Dah	Tamborine Hit	Tamborine Hit		Daholia Sak 1		
	73	C#	4	61	C#	3	Bongo L	Kendang Tipung Thung 1	Tamborine Hit Mute	Tamborine Hit Mute		Daholia Tak 1		
	74	D	4	62	D	3	Conga H Mute	Kendang Ciblon Dhen	Duf Open	Duf Open		Daholia Dom		
	75	D#	4	63	D#	3	Conga H Open	Kendang Ciblon Dhen	Duf Slide	Duf Slide		Daholia Tak 2		
	76	E	4	64	E	3	Conga L	Kendang Ciblon Thung	Duf Center Mute	Duf Slide Long		Tablah Prok		
	77	F	4	65	F	3	Timbale H	Kendang Ciblon Lung 1	Duf Slap Mute	Duf Slide Short		Tablah Dom 2		
	78	F#	4	66	F#	3	Timbale L	Kendang Ciblon Thak 1	Duf Ring Mute	Duf Palm Half Mute		Tablah Roll of Edge		
	79	G	4	67	G	3	Agogo H	Kendang Ciblon Thak 2	Bayan Duf Open	Duf Palm Slide 1		Tablah Tak Finger 4		
	80	G#	4	68	G#	3	Agogo L	Kendang Tipung Thung 2	Bayan Duf Slap Mute	Duf Palm Slide 2		Tablah Tak Trill 1		
	81	A	4	69	A	3	Cabasa	Kendang Tipung Ket	Bayan Duf Slide	Duf Mute		Tablah Tak Finger 3		
	82	A#	4	70	A#	3	Marcacas	Kendang Ciblon Lung 2	Bayan Duf Ring Mute	Tung Open 1		Tablah Tak Trill 2		
	83	B	4	71	B	3	Samba Whistle H	Kendang Ciblon Tong	Dayan Finger Tips 2	Tak Open Rim 2		Tablah Tak 1		
	84	C	5	72	C	4	Samba Whistle L	Plak 1 Ring Mute	Tung Finger Tips 1	Keplak Open		Tablah Tak Finger 2		
	85	C#	5	73	C#	4	Guiro Short	Plak 1 Mute Center	Tung Finger Tips 2	Keplak Mute		Tablah Tik 2		
	86	D	5	74	D	4	Tung Open	Tung Open	Dayan Finger Tips 1	Keplak Finger Tips 1		Tablah Tik 4		
	87	D#	5	75	D#	4	Claves	Low Dut Open	Dayan Ring Mute	Keplak Finger Tips 2		Tablah Tik 3		
	88	E	5	76	E	4	Wood Block H	Low Dut Mute 1	Dayan Finger Tips 3	Tak Open Center		Tablah Tik 1		
	89	F	5	77	F	4	Wood Block L	Low Dut Mute 2	Dayan Ring Open	Tak Open Rim 1		Tablah Tak 3		
	90	F#	5	78	F#	4	Cuica Mute	Low Dut Mute 3	Dayan Finger Tips 2	Tak Open Rim 2		Tablah Tak 1		
	91	G	5	79	G	4	Cuica Open	Low Dut Mute 4	Dayan Open	Tak Center Mute		Tablah Tak 4		
	92	G#	5	80	G#	4	Triangle Mute	Low Dut Slide 1	Dayan Center Mute	Tak Ring Mute		Tablah Tak 2		
	93	A	5	81	A	4	Triangle Open	Low Dut Slide 2	Tung Open	Prang Slap Mute		Tablah Sak 2		
	94	A#	5	82	A#	4	Shaker	Low Dut Slide 3	Plak 1 Mute Center	Prang Finger Tips Flam		Tablah Tremolo		
	95	B	5	83	B	4	Jingle Bells	Plak 2 Ring Open	Low Dut Mute 1	Plak 1 Ring Mute		Tablah Sak 1		
	96	C	6	84	C	5	Bell Tree		Low Dut Mute 3	Plak 1 Mute Center		Tablah Dom 1		
	97	C#	6	85	C#	5			Low Dut Slide 3	Tung Open 2				
	98	D	6	86	D	5			Plak 2 Mute Center	Low Dut Open				
	99	D#	6	87	D#	5			Plak 2 Open	Low Dut Mute 1				
	100	E	6	88	E	5				Low Dut Mute 2				
	101	F	6	89	F	5				Low Dut Mute 3				
	102	F#	6	90	F#	5				Low Dut Mute 4				
	103	G	6	91	G	5								

* Actual keyboard notes of the SFX Kit 1 and 2 are one octave lower than the ones described in the list.

		Voice No.		261	276	277	278	279
		MSB (0-127) / LSB (0-127) / PC (1-128)		127/000/001	126/000/041	126/000/001	126/000/002	126/000/113
		MIDI		Standard Kit 1	Cuban Kit	SFX Kit 1 *	SFX Kit 2 *	Sound Effect Kit
	Note #	Note	Note #	Note				
	25	C# 0	13	C# -1	Surdo Mute			
	26	D 0	14	D -1	Surdo Open			
	27	D# 0	15	D# -1	Hi Q			
	28	E 0	16	E -1	Whip Slap			
	29	F 0	17	F -1	Scratch H			
	30	F# 0	18	F# -1	Scratch L			
	31	G 0	19	G -1	Finger Snap			
	32	G# 0	20	G# -1	Click Noise			
	33	A 0	21	A -1	Metronome Click			
	34	A# 0	22	A# -1	Metronome Bell	Conga H Tip		
	35	B 0	23	B -1	Seq Click L	Conga H Heel		
	36	C 1	24	C 0	Seq Click H	Conga H Open		
C1	C#1	C# 1	25	C# 0	Brush Tap	Conga H Mute		
D1	D#1	D 1	26	D 0	Brush Swirl	Conga H Slap Open		
E1	E#1	D# 1	27	D# 0	Brush Slap	Conga H Slap		
F1	F#1	E 1	28	E 0	Brush Tap Swirl	Conga H Slap Mute		
G1	G#1	F 1	29	F 0	Snare Roll	Conga L Tip		
A1	A#1	F# 1	30	F# 0	Castanet	Conga L Heel		Drum Loop
B1	B#1	G 1	31	G 0	Snare Soft	Conga L Open		
C2	C#2	G# 1	32	G# 0	Sticks	Conga L Mute		
D2	D#2	A 1	33	A 0	Bass Drum Soft	Conga L Slap Open		
E2	E#2	A# 1	34	A# 0	Open Rim Shot	Conga L Slap		
F2	F#2	B 1	35	B 0	Bass Drum Hard	Conga L Slide		
G2	G#2	C 2	36	C 1	Bass Drum	Bongo H Open 1 finger	Cutting Noise 1	Phone Call
A2	A#2	C# 2	37	C# 1	Side Stick	Bongo H Open 3 finger	Cutting Noise 2	Door Squeak
B2	B#2	D 2	38	D 1	Snare	Bongo H Rim		Door Slam
C3	C#3	D# 2	39	D# 1	Hand Clap	Bongo H Tip	String Slap	Scratch Cut
D3	D#3	E 2	40	E 1	Snare Tight	Bongo H Heel		Scratch
E3	E#3	F 2	41	F 1	Floor Tom L	Bongo H Slap		Applause
F3	F#3	F# 2	42	F# 1	Hi-Hat Closed	Bongo L Open 1 finger		Wind Chime
G3	G#3	G 2	43	G 1	Floor Tom H	Bongo L Open 3 finger		Telephone Ring
A3	A#3	G# 2	44	G# 1	Hi-Hat Pedal	Bongo L Rim		Hiccup
B3	B#3	A 2	45	A 1	Low Tom	Bongo L Tip		Cuckoo Clock
C4	C#4	A# 2	46	A# 1	Hi-Hat Open	Bongo L Heel		Stream
D4	D#4	B 2	47	B 1	Mid Tom L	Bongo L Slap		Frog
E4	E#4	C 3	48	C 2	Mid Tom H	Bongo L Open		Rooster
F4	F#4	C# 3	49	C# 2	Crash Cymbal 1	Timbale L Open		Dog
G4	G#4	D 3	50	D 2	High Tom			Cat
A4	A#4	D# 3	51	D# 2	Ride Cymbal 1			Horse Gallop
B4	B#4	E 3	52	E 2	Chinese Cymbal		Flute Key Click	Car Engine Ignition
C5	C#5	F 3	53	F 2	Ride Cymbal Cup	Paila L		Car Tires Squeal
D5	D#5	F# 3	54	F# 2	Tambourine	Timbale H Open		Car Passing
E5	E#5	G 3	55	G 2	Splash Cymbal			Car Crash
F5	F#5	G# 3	56	G# 2	Cowbell			Siren
G5	G#5	A 3	57	A 2	Crash Cymbal 2			Train
A5	A#5	A# 3	58	A# 2	Vibraslap			Jet Plane
B5	B#5	B 3	59	B 2	Ride Cymbal 2	Paila H		Starship
C6	C#6	C 4	60	C 3	Bongo H	Cowbell Top		Burst
D6	D#6	C# 4	61	C# 3	Bongo L			Roller Coaster
E6	E#6	D 4	62	D 3	Conga H Mute			Submarine
F6	F#6	D# 4	63	D# 3	Conga H Open			
G6	G#6	E 4	64	E 3	Conga L	Guiro Short		
A6	A#6	F 4	65	F 3	Timbale H	Guiro Long		
B6	B#6	F# 4	66	F# 3	Timbale L			
C7	C#7	G 4	67	G 3	Agogo H			
D7	D#7	G# 4	68	G# 3	Agogo L	Tambourine	Shower	Laugh
E7	E#7	A 4	69	A 3	Cabasa		Thunder	Scream
F7	F#7	A# 4	70	A# 3	Maracas		Wind	Punch
G7	G#7	B 4	71	B 3	Samba Whistle H		Stream	Heartbeat
A7	A#7	C 4	72	C 3	Samba Whistle L	Maracas	Bubble	Footsteps
B7	B#7	C# 4	73	C# 3	Guiro Short	Shaker	Feed	
C8	C#8	D 4	74	D 3	Guiro Long	Cabasa		
D8	D#8	D# 4	75	D# 3	Claves			
E8	E#8	E 4	76	E 3	Wood Block H			
F8	F#8	F 4	77	F 3	Wood Block L			
G8	G#8	F# 4	78	F# 3	Cuica Mute			
A8	A#8	G 4	79	G 3	Cuica Open			
B8	B#8	G# 4	80	G# 3	Triangle Mute			
C9	C#9	A 4	81	A 3	Triangle Open			
D9	D#9	A# 4	82	A# 3	Shaker			
E9	E#9	B 4	83	B 3	Jingle Bells			
F9	F#9	C 4	84	C 3	Bell Tree	Dog	Machine Gun	
G9	G#9	C# 4	85	C# 3		Horse	Laser Gun	Applause 1
A9	A#9	D 4	86	D 3		Bird Tweet	Explosion	Applause 2
B9	B#9	D# 4	87	D# 3			Firework	Applause 3
C10	C#10	E 4	88	E 3				Applause 4
D10	D#10	F 4	89	F 3				
E10	E#10	F# 4	90	F# 3				
F10	F#10	G 4	91	G 3		Maou		
G10	G#10	G# 4	92	G# 3				
A10	A#10	A 4	93	A 3				
B10	B#10	B 4	94	B 3				
C11	C#11	C 5	95	C 4				
D11	D#11	C# 5	96	C# 4				
E11	E#11	D 5	97	D 4				
F11	F#11	D# 5	98	D# 4				
G11	G#11	E 5	99	E 4				
A11	A#11	F 5	100	F 4				
B11	B#11	F# 5	101	F# 4				
C12	C#12	G 5	102	G 4				
D12	D#12	G# 5	103	G# 4				