


YAMAHA

FINGER DRUM PAD

FGDP-30



	1	&	2	&	3	&	4	&	5	&	6	&	7	&	8	&
HH	x	x	x	x	x	x	x	x								
Snare																
Tom																
Kick																
	L	L	L	L	L	L	L	L	R	L	R	L	R	L	R	

Pad layout setting "Left" (When playing with the left hand) / Kit No.1, "Maple" selected

Scan for more information

